

Installation Manual

- 1) Do wiring according to the wiring diagram and power on the DALI system.
- 2) Install the “DALI Master” software on the operating computer:

Step 1: Run the installation file and select installation mode as shown in Figure

Step 2: Select installation language as shown in Figure 2.




Figure 1 Select Installation Mode




Figure 2 Select a Installation Language

Step 3: Select installation path as shown in Figure 3

Step 4: Create desktop shortcut as shown in Figure




Figure 3 Installation Path




Figure 4 Create Desktop Shortcut

Step 5: Starting installation as shown in Figure 5.

Step 6: Complete installation as shown in Figure 6.




Figure 5 Starting Installation




Figure 6 Complete Installation




Figure 7 Run this program as an administrator

NOTES:

1) Please install the software according the installation steps, otherwise it can not be started correctly.

2) This software is installed to disk C by default, if the installation path is not modified, please run the software as administrator, detailed method is as follows:

Step 1: Right click the desktop icon to check the properties, switch to "Compatibility" tab, and check item "Run this program as an administrator" as shown in Figure 7.

Step 2: Click "OK" to complete the setting as shown in Figure 7.

3) If you need to re-install the software, if you need to change the installation path please first uninstall previous installation, otherwise just install to cover the previous installation.

3) Install CH340 DRIVER

Step 1: Connect the USB communication port wire, double click the file "CH341SER.EXE" to install, as shown in Figure 8.

Step 2: If there is an indication that installation failed, please first uninstall the installation, then install again.




Figure 8 Double Click "CH341SER.EXE"




Figure 9 Driver Installation

Step 3: Right click "This PC", then click "Management", then click "Device Manager", then you can check whether the installation is successful or not as shown in Figure 11.




Figure 10 Driver Installation Successful

5) Follow the instruction of the PC configuration software to configure the master controller and control gears, for detailed operation please refer to the user manual of the PC software.